

NOTES:  
 1) FOR USE WITH THE T400 LATCH.  
 2) DIMENSION "X" IS VARIABLE DEPENDING ON DOOR THICKNESS.  
 MAKE SURE THE CENTER-LINE OF STRIKE IS SAME AS CENTER-LINE  
 OF LOCK CASE.  
 3) STRIKE LOCATION ON FRAME MUST BE ADJUSTED FOR THICKNESS  
 OF DOOR WHEN SILENCERS ARE USED.  
 4) FOR OPPOSITE HANDING, MIRROR DIMENSIONS TO OTHER SIDE  
 OF JAMB.  
 5) THE STRIKE AND LATCH SHARE THE SAME HORIZONTAL CENTERLINE.

Description:  
**T400 DEADBOLT STRIKE PREP  
 SQUARE CORNER**



1011 3rd Avenue S.W. Carmel, IN. 46032

TOLERANCES UNLESS  
 OTHERWISE SPECIFIED:  
 X.X (METRIC)=  $\pm 0.5$   
 X.XX(METRIC)=  $\pm 0.15$   
 0.00"(UNIFIED)=  $\pm .015"$   
 0.000"(UNIFIED)=  $\pm .005"$

Drawing No:  
**DP-482**

Drawn By: JDK

Orig.Date 09-04-24

Rev. Date: Rev.: Rev.:

