

NOTES:


- 1) FOR USE WITH THE T400 LATCH.
- 2) DIMENSION "X" IS VARIABLE DEPENDING ON DOOR THICKNESS. MAKE SURE THE CENTER-LINE OF STRIKE IS SAME AS CENTER-LINE OF LOCK CASE.
- 3) STRIKE LOCATION ON FRAME MUST BE ADJUSTED FOR THICKNESS OF DOOR WHEN SILENCERS ARE USED.
- 4) FOR OPPOSITE HANDING, MIRROR DIMENSIONS TO OTHER SIDE OF JAMB.
- 5) THE STRIKE AND LATCH SHARE THE SAME HORIZONTAL CENTERLINE.

Description:
**T400 DEADBOLT STRIKE PREP
 RADIUS CORNER**





TOLERANCES UNLESS OTHERWISE SPECIFIED:
 X.X (METRIC)= ±0.5
 X.XX(METRIC)= ±0.15
 0.00"(UNIFIED)= ±.015"
 0.000"(UNIFIED)= ±.005"

Drawing No: DP-483	
Drawn By: JDK	Orig.Date 03-04-25
Rev. Date:	Rev.:



SECTION A-A



STRIKE CENTER LINE
 SEE NOTE 5

TO BE DETERMINED BY
 GENERAL CONTRACTOR